


# Cennik

## JAZZ SILENT BOX




# JAZZ SILENT BOX




	Opis	Sz.	Gł.	Wys.	Symbol	Cena netto
	Upholstered acoustic walls of "Silent box" with black MDF legs	1810	925	1420	AGS180	6267,5

# JAZZ SILENT BOX

		Opis	Sz.	Gł.	Wys.	Symbol	Cena netto
	Upholstered acoustic walls of "Silent box" with black MDF legs	1810	2500	1420	AGS181	13892	



# JAZZ SILENT BOX



Opis		Sz.	Gł.	Wys.	Symbol	Cena netto	
						I GR	II GR
	Upholstered acoustic walls of "Silent box" with desk (1200x650, H=663) and black MDF legs	1810	2500	1420	AGS182	14271,5	14340,5


# JAZZ SILENT BOX



	Opis	Sz.	Gł.	Wys.	Symbol	Cena netto
	Left hand pouf for "Silent Box" with linking parts. Base - black painted metal.	800	600	400, SH=400	SGA1L0	1771
	Right hand pouf for "Silent Box" with linking parts. Base - black painted metal.	800	600	400, SH=400	SGA1R0	1771


# JAZZ SILENT BOX



		Opis	Sz.	Gł.	Wys.	Symbol	Cena netto
	Cushion		800	200	300	ZGZ005	540,5


# JAZZ SILENT BOX



Opis		Sz.	Gł.	Wys.	Symbol	Cena netto
	Metal table placed on the pouf	602	400	122	SGZ001	414

# JAZZ SILENT BOX





	Opis	Sz.	Gł.	Wys.	Symbol	Cena netto
	Metallic accessory "Do not disturb man" for screens	118	44	121	ZGZ003	161







# JAZZ SILENT BOX



	Opis	Sz.	Gł.	Wys.	Symbol	Cena netto	
						I GR	II GR
	Upholstered acoustic walls of "Silent box" with desk (1200x650, H=663), monitor holder, power socket, wires box and black MDF legs	1810	2500	1420	AGS183	14881	14950
	Upholstered acoustic walls of "Silent box" with desk (1200x650, H=663), monitor holder, power socket and USB fast charger, wires box and black MDF legs	1810	2500	1420	AGS184	16123	16192

# JAZZ SILENT BOX



	Opis	Sz.	Gł.	Wys.	Symbol	Cena netto	
						I GR	II GR
	Left hand pouf for "Silent Box" with power socket and linking parts. Base - black painted metal.	800	600	400	SGA109	2104,5	2679,5
	Right hand pouf for "Silent Box" with power socket and linking parts. Base - black painted metal.	800	600	400	SGA110	2104,5	2679,5
	Left hand pouf for "Silent Box" with USB fast charger and linking parts. Base - black painted metal.	800	600	400	SGA113	2553	3047,5
	Right hand pouf for "Silent Box" with USB fast charger and linking parts. Base - black painted metal.	800	600	400	SGA114	2553	3047,5